

1.0 - INSTALLATION INSTRUCTIONS - 118155-007 Rev. A

Install the PinPoint[®] Synchro[®] Cable

Models - Miller Sprayers and New Holland Sprayers

KIT NUMBER- 118703-008	
PART NUMBER	DESCRIPTION
118669-205	PinPoint [®] Synchro [®] Cable
118669-204	Adapter Harness
118669-203	Adapter Harness

For safety information see the system and machine manuals.

1. **[Figure 1]** - Locate the PWM cartridge (1) or pump servo just in front of the frame rail between the two rear wheels and remove the wire.

PWM cartridge will have a 2-pin Deutsch connector.

The pump servo will have a molded 2-pin connector use provided adapters to convert the molded 2-pin connections to the Deutsch connector.



Figure 1

- **IMPORTANT:** This step is only necessary for the PWM cartridge pump control. If a pump servo is installed go to Step 3.
- 2. **[Figure 2]** Install the 2-wire resistor adapter (1) supplied in the kit onto the wire removed from PWM cartridge in Step 1.
- 3. Install the Synchro[®] adapter cable (2) onto the 2-wire resistor adapter (if applicable) and into the PWM cartridge.
- 4. Route and secure the cable along the frame to the front of the sprayer to the existing PinPoint[®] wiring going to the Gateway hub. Avoid pinch points.



Figure 2



5. **[Figure 3] -** Install the 8-pin connection (1) in the Servo port on the Gateway hub.



Figure 3