

1.0 - INSTALLATION INSTRUCTIONS - 118155-009 Rev. A

Install the PinPoint® Synchro® Cable

- Models - AGCO RoGator RG900/1100/1300

KIT NUMBER- 118669-301	
PART NUMBER	DESCRIPTION
118669-206	Synchro® Conversion Harness - 35 ft

For safety information see the system and machine manuals.

- [Figure 1]** - Locate the PWM cartridge (1) just behind the throttle control on the remote fill station.




Figure 1

- [Figure 4]** - Remove the wire (1) with the 2-pin Deutsch connection from the PWM cartridge.
- Install the 2-wire resistor adapter (2), provided in the kit, onto the wire removed from PWM cartridge.




Figure 2

4. **[Figure 4]** - Install the Synchro[®] adapter cable (1) onto the 2-wire resistor adapter (2) and into the PWM cartridge (3).
5. Route and secure the cable along the frame towards the back of the sprayer and meeting up with existing PinPoint[®] wiring going to the Gateway Hub.

IMPORTANT: Make sure to keep the harnesses away from pinch points.




Figure 3

6. **[Figure 4]** - Plug in the 8-pin connection (1) into the Servo port on the Gateway Hub.




Figure 4